

### Hand Operated Motor Speed Control - Single Phase

Models 1 Amp, 3 Amp, 6 Amp and 10 Amp for all applications using suitable specified single phase induction motors.

#### WARNING

Mains voltage is present. Care must be exercised when adjusting pre-set potentiometer. It is the responsibility of the user to ensure compliance with the Health and Safety at Work Act.

#### GENERAL

The controllers utilise phase cutting techniques. Thus by manual adjustment of rotary control knob on the front of the controller, variable power may be applied to most permanent split capacitor, shaded Pole Motors.

Control is best achieved with propeller, axial or centrifugal fan loads, when absorbed power at full load corresponds to at least 90% of the motors capacity.


#### SPECIFICATION

Model Number	Run Current (Amps)	Maximum Start Current (Amps)	Fuse size (Amps/Length)
1.5 AMP	1.5 Amp	5	3.15 / 20mm
3 AMP	3 Amp	9	5 / 20mm
6 AMP	6 Amp	18	10 / 32mm
10 AMP	10 Amp	30	10 TD / 32mm

The 1,3,6,10 AMP Controllers are designed for continuous operation at 1 Amps, 6 Amps and 10 Amps maximum loads respectively at 40°C ambient, on single phase 230V 50/60 Hz. supply.

The controllers are compliant with CE requirements.

CONTROLLER WIRING DIAGRAM (for TK controllers Only)



## MOTOR PROTECTION

Fuses in the unit are for protection of the controller. Should this current rating exceed that of the wiring to the fans, individual fan protection should be provided. If overload protection for each fan is to be used, then this should be situated in each common line (UZ) only.


## INSTALLATION

Install in a dry sheltered position. Leave an airspace of not less than 15 CMS. around the controller to allow cooling air to flow freely. Do not install in close proximity to other heat sources. The maximum ambient temperature must not exceed 40° C.


Removing the front cover fixing screws allows access to mounting holes and terminals. If more fans need to be controlled a junction box can be used to parallel the various connections.

An external thermostat or switch can be fitted to enable fan to run at a preset speed adjusted by the controller and maximum speed set by temperature of the thermostat or operation of the switch. connect the thermostat or switch to the u and z of the controller as shown in the circuit diagram.

### CONTROLLER



### CONNECTIONS



VENT DIRECT Controller Terminal	Systemair	S & P	Woods	Elta SCP SCD	Elta SLC SMB SMC	Hydor	EBM-Ziehl	Vent Axia
EARTH	E	E	E	E	E	E	E	E
LIVE	L	L	L	L	L	L	L	L
NEUTRAL	N	N	N	N	N	N	N	N
Z		U*	P*	4	Z2		CAP.	U
U	U2	V	U	5	U1	N	U2	V
UZ	U1	W	UZ	6	U2	L	U1/Z1	W

\* Remove link between P and U (if fitted)

\* Remove link between U & V (if fitted)

Certain fans have inbuilt thermal protection labeled K.K or (TK.TK). If this facility is to be utilised then the wiring from controller UZ only should be connected to one of the thermal protection contacts, the other contact connected to the appropriate motor contact.

## CONTROLS

The controllers have separate ON/OFF switches. Rotating the control knob clockwise will increase the speed of the fan(s) from a preset minimum to full speed with infinitely variable control.

An internal mounted pre-set potentiometer sets the minimum speed of the fan(s). If this requires adjustment rotate the main control knob fully anti-clockwise and adjust the pre-set to required speed. Do not set this control too low since this will increase the risk of stall conditions.